



BONA MIX&FILL

Sitework

Surface preparation

The surface to be filled must be clean, dry and free from contamination. New floors and old floors should be sanded back to bare wood. A sandpaper grade no. 100-120 should be used for the final sanding of the wood. The sanding dust from this sanding should be retained.

Application

Shake well prior to use. Mix&Fill should be mixed with the retained sanding dust to a texture suitable for application using a steel spatula. This should then be applied across the whole surface of the floor. Larger joints may require additional applications. N.B. Mix&Fill is not suitable for floors with joints larger than 2 mm.

Application rate: approx. 1 litre/10 m², depending upon the quantity/depth of the joints.

Drying time: approx. 20 minutes at 20°C/55% R.H. This time may be extended where deep or wide joints are filled.

After the Mix&Fill has dried the surface of the floor should be sanded back to bare wood using an abrasive grade no. 100-120 and, if required, finished using the Bona Scrad system. The floor may then be treated using any of Bona finishes or oils.